ELCO Lighting
Innovation Beyond Expectation

Round Monopoint Canopy Track Accessory
EP811, EP816 & EP819
Installation Instructions


WARNING:
Risk of electric shock. Before installation, disconnect power to the luminaire. Failure to do so may result in electric shock and lead to injury or death.
Risque de choc électrique. Avant l'installation, débranchez l'alimentation au luminaire. Ne pas le faire peut entraîner un choc électrique et entraîner des blessures, voire la mort.

CAUTION:
For your safety, read and understand instructions completely prior to installation. Installation requires knowledge of luminaires electrical system. If not qualified, DO NOT attempt installation. Contact a qualified electrician if necessary.
Pour votre sécurité, lisez et comprenez entièrement les instructions avant l'installation. L'installation nécessite une connaissance du système électrique des luminaires. Si vous n'êtes pas qualifié, NE PAS tenter l'installation. Contactez un électricien qualifié si nécessaire.

NOTE: Before beginning the installation, carefully unpack and identify all parts. **Save these instructions as you may need them at a later date.**

MOUNTS PERMANENTLY TO OUTLET BOX.
ALLOWS ANY LAMPHOLDER UP TO 300W MAXIMUM TO BE CONVERTED TO CANOPY INSTALLATION

1. Attach Mounting Plate to Junction Box by two Mounting Screws provided.
2. Hold the cover and attach BK fixture wire to BK house wire, WH fixture wire to WH house wire, Green fixture wire to Green house wire by wire connectors provided.
3. Tuck the wires into the Outlet Box.
4. 4. Fix the cover over the Mounting Plate by two set screws.



TO INSTALL THE TRACK HEAD:

1. Insert the Adaptor head into the slot of Monopoint cover.
2. Pull down the sleeves and twist Adaptor about 90 degree until mounting sleeves tab locks into the Monopoint slot.
3. Note forcing mounting adaptor in wrong direction may damage the contact assembly. Polarity tab on Adaptor must align with polarity groove on Monopoint for proper installation.

TO REMOVE THE TRACK HEAD:

1. Pull down mounting Adaptor sleeves and twist adaptor 90 degree until Adaptor is free from the opening of Monopoint.

2042 East Vernon Ave. Vernon, CA 90058 • Tel: (323) 231-2600 Fax: (323) 231-3200 □ www.elcolighting.com

ALL RIGHTS RESERVED © ELCO Lighting 2026